



### **MISFIT SERVICE BULLETIN**

Flip the chain adjuster plates around so the concave side faces in toward the front of the bike. Make certain the sides line up straight. Adjust chain. The inner nut will lock itself in place in the grooved edges of the plate. Tighten the second nut when the chain adjustment is complete.